IFS4102 LAB WEEK 4

OBJECTIVES

- I. Inspect disk image file using TSK (Task I)
- 2. Perform file signature analysis and fix mismatched extensions (Task 2)
- 3. Extract and view metadata of Microsoft office files and image files (Task 3-A&B)
- 4. Using Autopsy to extract deleted files and execute ingest modules (Task 4-A,B,C&D)

REMINDER: WEEK 4 GRADED LAB TASKS #2 SATURDAY, II FEBRUARY 2023, 23:59 SGT USE THE GIVEN SAMPLE FILES

- I. For questions I & 2, use **SuspectDrive I.E01**
- 2. For question 3, use **SecretFile.docx**

- Linux forensic workstation
- Open-sourced, CLI toolkit for analysing Microsoft and UNIX file systems and disk
- Autopsy is the GUI of TSK

- TSK is a command line utility:
- More like a toolkit rather than an application:
 - img_stat
 - mmstat
 - mmls
 - fsstat
 - fls
 - and more at https://github.com/sleuthkit/sleuthkit/tree/develop/man

- Tool: img_stat
- What it does? Displays information of a disk image file
- Typical usage:
 - img_stat <imagefile>
 - Output:
 - Image type
 - Size of data
 - Sector size
 - MD5 Hash
- Output of img_stat is used as input for other tools in TSK, should always run img_stat first.
- Note down image type



- Tool: mmstat
- What it does? Displays detail about the volume system (i.e., partition table)
- Typical usage:
 - mmstat <imagefile>
 - Output: partition table type (e.g., dos)
- Usually I use mm1s to check the type of partition, but can use both to double check make sure the type matches.

- Tool: mmls
- What it does? Displays partition layout of a volume system, including unallocated spaces.
- Typical usage:
 - mmls <imagefile>
 - Output:
 - type of partition table (e.g., dos)
 - Offset sector
 - Sector size
 - Layout of the disk in table form
 - Index
 - **Start** and end sector number
 - Length
 - File System Type


- Tool: mmls
- Output of mmls is used as input for other tools in TSK, should always run mmls.
- Note down the file system type and associated start sector number

```
-(kali®kali)-[~/Desktop/Forensics Lab/drive]
   mmls SuspectDrive1.E01
DOS Partition Table
Offset Sector: 0
Units are in 512-byte sectors
      Slot
                                                        Description
                Start
                             End
                                          Length
                                          0000000001
                                                        Primary Table (#0)
000:
     Meta
                0000000000
                             0000000000
                                                       Unallocated
001:
                                          0000000032
                0000000000
                             00000000031
                                                       Win95 FAT16 (0×0e)
002:
     000:000
               0000000032
                             0003914751
                                          0003914720
```

- Tool: fsstat
- What it does? Displays the general details of a file system
- From img_stat and mmls, identified image type, file system type and start offset.
- Typical usage:
 - fsstat -i list
 - fsstat -f list
 - fsstat -i <image type> -f <file system type> -o <starting offset> <imagefile>
 - fsstat -i ewf -f fat16 -o 32 SuspectDrive1.E01

- Output: 4 sections
 - File system information
 - Metadata information
 - Content information
 - FAT content

File system information




- Metadata information
 - Valid range of addresses to use with icat or istat
 - Based on total number of sectors in the file system
 - Not very important for us, this slide is FYI.

METADATA INFORMATION


Range: 2 - 62627846 Root Directory: 2

Content information



- FAT contents (to be discussed in Lecture 5)
 - Graphical representation of the primary FAT structure.
 - Each line corresponds to a "cluster run"
 - If cluster is not allocated then no entry in this section

- Not always I cluster
- Sector 1344 to 1727 = 384 sectors
- This file allocated 6 consecutive cluster (384/64=6)
- Grouped together if consecutive, otherwise, instead of → EOF, will see → (sector number)



- Tool: fls
- What it does? List file and directory names in a disk image
- From img_stat and mmls, identified image type, file system type and start offset.
- Typical usage (similar to fsstat):
 - fls -i list
 - fls -f list
 - fls -i <image type> -f <file system type> -o <starting offset> <imagefile>
 - Above command only show directory listings
 - -r show all files, -p show full pathnames, -l show MAC time (-l is lower case L).

File type. First letter is saved in file name structure. Second letter saved in metadata structure.

For allocated files, should always be equal. For delete files, could be different.

Types: r = regular file, d = directory, c = character device, b = block device, l = symbolic link, p = named FIFO, s = shadow,

h = socket, w = whiteout, v = TSK virtual file/directory (not a real directory, created by TSK for convenience)

```
'-I' (lower case L) show, in order, last modified time, last accessed time, last changed time, created time, size in bytes, UID, GID
      Metadata address
  ·(kali®kali)-[~/Desktop/Forensics Lab/drive
              -f fat16 -o 32 -r -l
                   (Volume Label Entry)
       System Volume Information
               WPSettings.dat 2020-02-09 04:14:52 (EST)
                       2020-02-09 19:30:50 (EST)
               Password-list.txt
                                       2020-02-09 19:36:00 (EST)
                                                                      2020-02-09 00:00:00 (EST)
                                                                                                                                      2020-02-09 19:33:42 (EST)
               Password-again.txt
      Friends 2020-02-09 19:30:56 (EST)
                                               2020-02-09 00:00:00 (EST)
                                                                              0000-00-00 00:00:00 (UTC)
                                                                                                              2020-02-09 19:30:55 (EST)
               Mjk0MDIuanBn.jpg
               Mjk0MDIuanBn.jpg.crdownload
+ r/r 4622:
                                       2020-02-09 19:48:22 (EST)
                                                                                                                                                                     26371
               Mjk0MDIuanBn.jpg
                                                                      2020-02-09 00:00:00 (EST)
                                                                                                                                      2020-02-09 19:48:32 (EST)
```

If -r is used, '+' is added to the front of each entry to show how deep the file is. In this example, password-list.txt is I directory deep, in the personal directory


File/directory name

means deleted

- Documentation
 - https://github.com/sleuthkit/sleuthkit/tree/develop/man
 - Use the tool without argument, example: img_stat

2. PERFORM FILE SIGNATURE ANALYSIS AND FIX MISMATCHED EXTENSIONS (TASK 2)

- Use hex editor WinHex or FTK Imager
- Use online library https://www.garykessler.net/library/file_sigs.html
- Using the online library, find specific patterns in the header and/or footer which will help identify the correct extension.



3. EXTRACT AND VIEW METADATA OF MICROSOFT OFFICE FILES AND IMAGE FILES (TASK 3-A&B)

Task 3A

- Change Microsoft Office file to .zip extension
- Open and navigate to docProps > core.xml
- Inspect metadata

Task 3B

Use web-based tool http://exif.regex.info/exif.cgi

4. USING AUTOPSY TO EXTRACT DELETED FILES AND EXECUTE INGEST MODULES (TASK 4-A,B,C&D)

- Introduced Autopsy last week, manual analysis
- Automated analysis using Ingest modules
- Demo with "SuspectDrive1.E01"
 - Task 4-A: Filter all deleted files (Automatic once add data source, no need to run any ingest modules)
 - Task 4-B: Perform File Type identification based on internal signatures (Ingest module: File Type Identification)
 - Task 4-C: Identify mismatched extensions (Ingest module: File Type Identification and Extension Mismatch Detector)
 - Task 4-D: Find if a file exist using hash-lookup (Ingest module: Hash Lookup)

= demo just now/inside lab notes

Ingest Modules

Ingest modules are responsible for analyzing the data source contents and will run in the background. The Ingest Modules analyze files in a prioritized order so that files in a user's directory are analyzed before files in other folders. Ingest modules can be developed by third-parties

The standard ingest modules included with Autopsy are:

- . Recent Activity Module extracts user activity as saved by web browsers and the OS. Also runs Regripper on the registry hive.
- Hash Lookup Module wes hash sets to ignore known files from the NIST NSRL and flag known bad files. Use the "Advanced" button to add and configure the hash sets to use during this process. You will get updates on known bad file hits as the ingest occurs. You can later add hash sets via the Tools -> Options menu in the main UI. You can download an index of the NIST NSRL from http://sourceforge.net/projects/autopsy/files/NSRL/
- File Type Identification Module determines file types based on signatures and reports them based on MIME type. It stores the results in the Blackboard and many modules depend on this. It uses the Tika open source library. You can define your own custom file types in Tools, Options, File Types.
- Extension Mismatch Detector Module uses the results from the File Type Identification and flags files that have an extension not traditionally associated with the file's detected type. Ignores 'known' (NSRL) files. You can customize the MIME types and file extensions per MIME type in Tools, Options, File Extension Mismatch.
- Embedded File Extraction Module opens ZIP, RAR, other archive formats, Doc, Docx, PPT, PPTX, XLS, and XLSX and sends the derived files from those files back through the ingest pipeline for analysis.
- Picture Analyzer Module expacts EXIF information from JPEG files and posts the results into the tree in the main UI. Also converts HEIC/HEIF files to JPEG format and extracts EXIF data from those JPEGs.
- Keyword Search Module uses keyword lists to identify files with specific words in them. You can select the keyword lists to search for automatically and you can create new lists using the "Advanced" button. Note that with keyword search, you can always conduct searches after ingest has finished. The keyword lists that you select during ingest will be searched for at periodic intervals and you will get the results in real-time. You do not need to wait for all files to be indexed before performing a keyword search, however you will only get results from files that have already been indexed when you perform
- . Email Parser Module identifies Thunderbird MBOX files and PST format files based on file signatures, extracting the e-mails from them, adding the results to the Blackboard.
- Encryption Detection Module looks for encrypted files.
- Interesting Files Identifier Module searches for files and directories based on user-specified rules in Tools, Options, Interesting Files. It works as a "File Alerting Module". It generates messages in the inbox when specified files are found.
- Central Repository Module adds file hashes and other extracted properties to a central repository for future correlation and to flag previously notable files.
- . PhotoRec Carver Module carves files from unallocated space and sends them through the file processing chain.
- . Virtual Machine Extractor Module extracts data from virtual machine files
- . Data Source Integrity Module computes a checksum on E01 files and compares with the E01 file's internal checksum to ensure they match.
- . DJI Drone Analyzer extracts data from drone files.
- Plaso uses Plaso to create timeline events
- · Android Analyzer Module allows you to parse common items from Android devices. Places artifacts into the BlackBoard.
- . GPX Analyzer extracts geolocation data from .gpx files.
- . iOS Analyzer (iLEAPP) extracts data from iOS data sources.

a.k.a. Exif parser

http://sleuthkit.org/autopsy/docs/user-docs/4.19.2/quick_start_guide.html

QUESTIONS?

REMINDER: WEEK 4 GRADED LAB TASKS #2 SATURDAY, I I FEBRUARY 2023, 23:59 SGT USE THE GIVEN SAMPLE IMAGE FILE

- I. For questions I & 2, use **SuspectDrive I.E01**
- 2. For question 3, use **SecretFile.docx**

Also, Week 3's graded task if you have not submitted.